142mm



Short press the gear switch/cruise control button to switch between three speed settings: 30%, 60%, and 100%. Long press the gear shift/cruise control button, the remote control indicator light will flash, press forward or backward to activate cruise control. Press and hold the gear switch / cruise control button again to stop cruise control. (Kind reminder: Do not use this function when operating on the desktop, please use it in an open area)

Short press the light/one key demonstration button to turn on or off the lights. Long press the light/one key demonstration button to activate the one key demonstration. Press any button to stop.

Precautions for battery use

1) The car's battery is non-replaceable but rechargeable. The remote control uses replaceable button batteries (Model: CR2032). Battery replacement must be done under adult supervision, as swallowing batteries is dangerous!
2) The removal and insertion of batteries should be operated according to the polarity and voltage markings on the battery box;
3) Non rechargeable batteries cannot be charged;
4) Rechargeable batteries must be charged under adult supervision;
5) Different types of batteries or old and new batteries cannot be mixed;
6) Only batteries that are the same or equivalent to the recommended battery can be used;
7) The exhausted battery should be removed from the product; If not used for a long time, please remove the battery from the product;
8) The power terminal must not be short circuited;
9) Regularly check whether the wires, plugs, shells, and other components are damaged. If any damage is found, stop using them until they are repaired. The model can only use the recommended USB cable, and models that can be cleaned with liquid should be disconnected from the USB cable before cleaning.

Precautions

1. This product must be assembled and used under adult supervision.
2. This product contains small parts, please do not swallow to avoid the risk of suffocation.
3. This product is not suitable for children under three years old.
4. If there are radio signals nearby, it will interfere with the signal reception of the dump truck, affecting normal operation. Please change the location and operate again.
5. Please do not dispose of the dismantled parts at will to avoid damaging environmental hygiene.
6. Do not place the product in a fire, high temperature, or damp place.
7. When the battery is wet with water, please clean it with a dry cloth.

97mm

Mini Remote-Controlled Dump Truck Instruction Manual

Please read the instructions carefully before use, and store them properly for future reference.

Product Content



Component Description

When the frequency is matched, the LED light at the front of the vehicle flashes. When the matching is successful, the LED light at the front of the vehicle remains constantly on

Dump truck



Green light on when charging, green light off when fully charged

Remote control



Mobile APP

Scan the QR code
Download and install

Note: When using the mobile phone APP to control the car, please turn off the power of the remote control first to avoid the remote control interfering with the operation of the APP

Charging Instructions

1. Remote control battery replacement

Unscrew the screws on the battery cover of the remote control, then slide out the battery cover. Place the 3V CR2032 button battery with the negative terminal facing down against the conductive sheet into the battery compartment, and then close the battery cover.



2. USB charging for dump truck

(1) Insert one end of the USB charging cable into the computer socket.
(2) Turn off the power of the dump truck and insert the other port of the USB charging cable into the dump truck charging port. When charging, the indicator light is on.
(3) After about 60 minutes of charging, the charging indicator light will turn off, indicating the end of charging. The dump truck can drive for about 20 minutes with sufficient power.



Attention

1. Do not pull or tug on the charging cable and plug during the charging process.
2. Please ensure that the product is fully discharged before charging to avoid overcharging that may affect the battery's lifespan.

Storage method

1. After use, wipe the dust off the dump truck clean and store it, and pack the dump truck and place it in a dry and well ventilated place.
2. After use, turn off the dump truck and remote control switch to improve battery life,
3. Before using it again, check if the power of the dump truck and remote control is sufficient.

Operation Guide

Before driving, please turn on the remote control and the power supply on the dump truck. The remote control and dump truck indicator lights will be on continuously, and the frequency matching will be successful. Then, place the dump truck on a flat surface. After 3 minutes without any operation, enter sleep mode and need to press the power switch again to restart.

1. Push the "Forward" joystick and the dump truck will move forward.



2. Push the "Reverse" joystick to drive the dump truck backwards.



3. Push the "Left turn" joystick, and the dump truck will turn left



4. Push the "Right turn" joystick, and the dump truck will turn to the right



5. Dump truck body lifting mode



Power switch / Music switch



Press the power switch briefly to turn on the device, and press the on/off music briefly;
Press and hold the power switch to turn it off.